



# UniverSeal US-100 Liquid Tape™ Installation Instructions

## Polyether Sealant, Vertical Seam Sealer

### Application

- Surface must be clean and free from dirt, oil & debris
- Do not apply below 32°F (0°C), due to frost
- Do not apply the membrane to a substrate that has absorbed water
- Maintain UniverSeal US-100 at room temperature before applying