



Wasco-Seal Plus™ Installation Instructions

Flexible Membrane

Joining of Material: Joint shall be made by lapping a minimum of 6" and coating the contacting surfaces with a construction adhesive or sealant, like York's UniverSeal US-100.